

Archive printer parameter

You don't want to imagine your printer losing all its settings due to a malfunction and going back to factory defaults. Or that a wrong configuration is accidentally sent to the printer with the same result: the printer settings having to be reset. Fortunately, it doesn't happen very often, but to avoid having to re-enter all the printer settings manually, we recommend that you make a copy of your settings.

The settings can be found on your printer under the name 'CLARITY-parameter archives'. The following explains how to make a copy and how to restore the copied settings to your printer if necessary.

Make a parameter archive backup

Back up your parameter archive by following the steps below:

- 1. Connect a USB stick to PC/Laptop and format the USB stick to a FAT32 file system.
- 2. Insert the USB stick in the bottom of the display (in the USB port).
- 3. Press the cogwheel/key (depending on your printer type) at the top right of the screen.

	RUNNING			
	Home			09:37 03/05/2021
	JOB Zodiac 2inch printer TEST			
\mathbf{U}	Performance			Consumables
0	Throughp	but	O p/m	Ribbon
#	Batch Co	ount	0	
\diamondsuit	iAssurance		100%	

- 4. Select Setting .
- 5. Choose Control.
- 6. Choose CLARITY-parameter archives.

	RUNNING	×
	Tools→Setup→Control	•
lacksquare	CLARITY Parameter Archives	>
\mathbf{O}	CLARITY Printer Clones	>
	Internationalisation	>
\bigcirc	Recalibrate Touchscreen	>
	Set Screen Orientation	0 Degrees >
	Date And Time	>
\diamondsuit	Communications	>



7. Choose Create archive > Name the parameter archive here or leave the default name (e.g. Z0295F1 03May2021 093615).

		F	NUN	NING		×
٢	Tools→Setup- Z0295F	• ^{Control} →Cr 1 03Ma	eate Arc ay202	^{shive} 21 0930	615	<
0	Q W	E R	Т	YU	I O P	Ø
	А	S D	F	GH	I J K	L
	1 Z	x c	V	B N	M ! ?	
	.?123	•			.?123	ê
		Cancel			ОК	

- 8. Press 'OK'.
- 9. At the bottom of the screen, the status bar (green) will change from 0% to 100%.

	RUNNING	X
	Tools→Setup→Control→Create Archive	•
U	 Create Archive 	
0	CLARITY Parameter Archive (20295F1 03May2021 093615' successfully created.	
\bigcirc		
#		
\diamondsuit	ОК	

10. Press 'OK'.

If you have followed the steps described above, you have now finished making a backup of the parameter settings on your printer. You now have a backup in case you need to unexpectedly re-enter the settings of your printer. You will find the copy you made on the USB stick in the Archives folder.

Restoring the parameter archive

To restore the parameter archive to the printer, follow the steps below:

- 1. Insert the USB stick into the USB port in the bottom of the display.
- 2. Press the cogwheel/key (depending on your printer type) at the top right of the screen.

			×	
	Home			09:37 03/05/2021
	JOB	Zodiac	2inch printer TEST	
U	Performance			Consumables
	Throughput		O p/m	Ribbon
#	Batch Count		0	
\diamondsuit	iAssuran	ce	100%	8%

3. Select Setting.



- 4. Choose Control.
- 5. Choose CLARITY-parameter archives.

	RUNNING	×
	Tools→Setup→Control	•
lacksquare	CLARiTY Parameter Archives	>
\mathbf{O}	CLARITY Printer Clones	>
	Internationalisation	>
\bigcirc	Recalibrate Touchscreen	>
-	Set Screen Orientation	0 Degrees >
	Date And Time	>
\diamondsuit	Communications	>

6. Find the relevant archive name and click on it. Your choice will turn blue or a tick will appear in front of your choice (depending on the type of printer).

If you do not find the right archive, check whether it is on the USB stick in the Archives folder.

	RUNNING					
	Tools→Setup→Control→CLARiTY Parameter Archives	◄				
U	Available Archives					
	Z0295F1 07feb2019 105206					
	Z0295F1 13Apr2021 135209					
	Z0295F1 13Apr2021 135255					
	Z0295F1 13Apr2021 135705					
=	✓ Z0295F1 03May2021 093615					
\diamondsuit	Create Archive Restore Archive					

- 7. Choose Restore archive.
- 8. The screen displays 'Are you sure you want to install the CLARITY parameter archive *file name*?' Select 'Yes'.



9. The screen displays 'The CLARITY parameter archive *file name* contains network settings. Would you like to restore the network settings?' Select 'Yes'.





10. When prompted to 'Would you like to restore the password settings?', click 'Yes' if the password has been activated and/or changed, otherwise click 'No'.

	RUNNI	NG 🕺		
	+ Control + Restore Archive + CLAR	TY Parameter Archives		
\mathbf{O}	CLARITY Parameter Archives			
	The CLARITY Parameter Archive 'Z0295F1 03May2021 093615' contains password settings.			
\mathbf{U}	Would you like to restore the password settings?			
0				
+				
\diamond	No	Yes		

11. At the bottom of the screen, the status bar (green) will change from 0% to 100%.



12. Press 'OK'.

If you have performed all the above actions, the settings (parameters) from your parameter archive will now be on your printer again.

Do you need support?

Do you still have any questions or do you need any help? For technical support or in the event of problems, you can contact our helpdesk on service@automator.nl or calling +31 (0)10 415 64 00.